


Ermetika[®]
I N S I D E W A L L S




**KOOSTE- JA
PAIGALDUSJUHE
SETUP INSTRUCTION**


Evokit absolute

PAKENDI SISU | CONTENTS


Standardvarustus (2 pakendit) / Standard equipment (2 packages)



Tööriistad - Tools




Üldine vaade - Overall view




SISUKORD - INDEX

Koostamine 100 mm seinale - Setup for 100 finished wall	3-6
Koostamine 125 mm seinale - Setup for 125 finished wall	7-10
Seina viimistlemine - Setup plasterboard	11-12
Perimeetriprofiilide pahteldamine - Perimeter profiles plastering	13


1.1







1.2




1.3




1.4




2.1







2.2




2.3




2.4



3.1




3.2




Subject to misprints, errors and technical modifications.
All dimensione are in mm

3.3

HORISONTAALNE LÕIGE - HORIZONTAL SECTION



VERTIKAALNE LÕIGE - VERTICAL SECTION



3.4

