



Setting of interior door hinges 6540KS.

Lowering the door leaf:

1. Loosen the lower set screws of the hinges with the hex key 1 equally counter-clockwise - the door leaf will move down under its own weight.
2. Tighten the upper set screws clockwise.

Lifting the door leaf:

1. Using the hex key 1, turn the two lower set screws open by two turns.
1. Tighten the upper set screws equally on all hinges until the door leaf is at the desired height.
2. Tighten the upper set screws. Setting range $\pm 1.5\text{mm}$.